


# DS-700/DS-700AC Firmware Update Procedure

This document describes how to update the firmware of DS-700/DS-700AC.

The firmware can be upgraded using the Web browser interface of DS-700/DS-700AC which can be accessed using the SX Virtual Link utility. Before you start, please make sure that both your PC and DS-700/DS-700AC are connected to a wired network.

\* This document uses the screenshots captured from Windows 10. However, the procedure will be the same if you are using an OS other than Windows 10.

1. Start the SX Virtual Link utility. Right-click the device server on SX Virtual Link's main window and select **Display the Web page** from the menu displayed.




\*Display may vary depending on the Web browser.

2. The login page is displayed. Enter the password for DS-700/DS-700AC and click **Login**.




\* When the login password configuration page appears, enter the password to configure for DS-700/DS-700AC. After the login password is configured, enter it at the login page.

3. After the login, the configuration page is displayed. Click **Firmware Update** under **Maintenance**.



4. The **Firmware Update** page appears. Click the button to the right of **New firmware**, and select the firmware file (\*) that has been downloaded to the PC, and click **Update**.

(\*) For DS-700, the name of firmware file will be "DS-700.bin".  
For DS-700AC, the name of firmware file will be "DS-700AC.bin".



5. The update confirmation message is displayed. Click **OK** to begin the firmware upgrade.



\* Do not turn off DS-700/DS-700AC or close your Web browser while the firmware upgrade is in process.

6. When the login page is displayed, the firmware update is completed. See the bottom left of the page and check the version information is changed.