


# Firmware Update Procedure

This document describes how to update the firmware of SX-AP-4800AN2.

The firmware can be updated using the Web browser interface of SX-AP-4800AN2. Before you start, please make sure that both your PC and SX-AP-4800AN2 are connected in a wired network.


\* This document uses the screenshots captured from Windows 10. However, the procedure will be the same if you are using an OS other than Windows 10.  
\* Display may vary depending on the Web browser.

**1** Start a Web browser on the PC and enter the IP address of SX-AP-4800AN2 in the address bar. Press the Enter key.




\* Above IP address is a sample address.  
Enter the IP address configured to SX-AP-4800AN2.

**2** The login page of SX-AP-4800AN2 is displayed. Enter the password of SX-AP-4800AN2 and click **Login**.




\* When the password configuration page is displayed, configure the password and then login.

**3** When the Web page of SX-AP-4800AN2 is displayed, click **Firmware Update** under **Maintenance**.



**4** The **Firmware Update** page appears. Click the button to the right of **New firmware**, and select the latest firmware (SX-AP-4800AN2.bin) that has been downloaded to the PC, and click **Update**.



**5** The update confirmation message is displayed. Click **OK** to begin the firmware update. Please wait until the update is complete.



\* Do not turn off SX-AP-4800AN2 or close your Web browser while the firmware update is in process.

**6** When the login menu is displayed, the firmware update is complete. In the bottom left of the Web page, check that the version information is changed.

If you have any issues, please contact our Customer Support Center.