

# AP-100AH/BR-100AH Firmware Update Procedure

This document describes how to update the firmware of AP-100AH/BR-100AH.

1. Access the internal Web page of AP-100AH/BR-100AH. To access the internal Web page, open your Web browser and enter the IP address of AP-100AH/BR-100AH into the address bar and press Enter key.
2. When you have connected to the AP-100AH/BR-100AH, you will get the **System Status** page. Click **Login** on the left side of the screen.

**NOTE:**

- Display may vary depending on the Web browser.
- When the password is not configured to AP-100AH/BR-100AH, the **Password Configuration** page is displayed.

3. Enter the password for the unit and click **Login**.
4. You will return to the **System Status** page, but new options will be listed on the left side of the screen. In the Web page, click **Firmware Update** on the left menu. In the **Firmware Update** page, click the button to the right of **New firmware**, and select the firmware file (APBR-100.bin) that has been downloaded to the PC.
5. Check the correct file name is displayed in **New firmware** field and click **Update**.
6. The update confirmation message is displayed. Click **OK** to begin the firmware upgrade.

**NOTE:**

Do not turn off AP-100AH/BR-100AH or close your Web browser while the firmware upgrade is in process.

7. When the **System Status** page is displayed, the firmware update is completed. See the bottom left of the page and check the version information is changed.

Silex Technology America, Inc.

<https://www.silextechnology.com/>

Technical Support: [support@silexamerica.com](mailto:support@silexamerica.com)

Sales: [sales@silexamerica.com](mailto:sales@silexamerica.com)